

Hinweise zu Druckdaten für Papiertaschen

Freehand MX2004, MX, 10, 9, 8, 7, 5, 3, PhotoShop bis Version CS5

(dazu gehören psd, tif, fpg, bmp, gif, pic, eps) Illustrator bis Version CS5.

1. Bilder / TIF- oder EPS-Dateien im Dokument einbetten oder mitliefern.
2. PDF-Files immer zusätzlich zur Originaldatei mit senden.
3. Bitte alle verwendeten Schriften immer in Kurven / Pfade konvertieren.
4. Bitmap-Dateien in Farb- oder Graustufen-Modus sollten eine Auflösung von 350 dpi.
5. Daten entweder in Euroskala CMYK oder in der gewünschten PANTONE Farbe liefern.
Bei Druck nach CMYK wir ohne Vorlage eines Cromalin keine Haftung für das
Druckergebniss übernommen. Reklamationen können nicht anerkannt werden.
6. Beschnittzugabe / Überfüller von ca. 2-3mm zu allen Richtungen anlegen.

Datas for paperbags:

Freehand MX2004, MX, 10, 9, 8, 7, 5, 3, PhotoShop until Version CS5

(incl. psd, tif, fpg, bmp, gif, pic, eps) Illustrator until Version CS5.

1. Pictures / files TIF- or EPS- inserted in artwork must be also sent separately.
2. Always send PDF Files in addition to the original files.
3. Please always convert all used writings in curves / paths.
4. By grey or colored Bitmap Files is a resolution of 350 dpi necessary .
5. Please mention pantone references with files.
for 4- colour process without a proof/cromalin , we cannot admit any claim
6. Create a cutting line of approx. 2-3 mm in all directions.